

# Germansell

**CarStyle**

Land Rover Discovery 3 Baujahr 2004 - 2009



BRAND	MODELS	V.TYPES	VERSION	TYPE APPROVAL
LANDROVER	DISCOVERY 4	-	2009 ≥	-

(EN) FITTING INSTRUCTIONS	: PORT BAGAJ	: ROOF RAIL
(TR) MONTAJ TALİMATI	: DACHRELING	
(FR) INSTRUCTIONS DE MONTAGE	: RIDELLES DE TOIT	
(ES) INSTRUCCIONES DE MONTAJE	: BARRAS DE TECHO	
(RU) ИНСТРУКЦИЯ ПО УСТАНОВКЕ	: РЕЙЛИНГИ	

(DE) TEILELISTE  
(EN) PART LIST

(FR) LISTA DE ACCESORIOS

(ES) LISTA DI PEZZO  
(RU) СПИСОК ДЕТАЛЕЙ

(DE) UNTERLEGSCHIEBE : 6 STÜCK  
(EN) RING WASHER : 6 PIECES



(FR) TUARCE : 6 PIÉZAS  
(ES) RONDELE AUTOBLOQUANTE : 6 PIECES  
(RU) ШАЙБЫ : 6 ШТУКИ



(DE) GUMMISTOPFEN : 6 STÜCK  
(EN) PLASTIC PLUG : 6 PIECES



(FR) BOUCHON PLASTIQUE : 6 PIÉZAS  
(ES) EMPAQUE PARATORNILLO : 6 PIECES  
(RU) РЕЗИНОВЫЕ ПРОБКИ : 6 ШТУКИ



(DE) KUNSTSTOFF-DICHTUNG : 6 STÜCK  
(EN) PLASTIC GASKET : 6 PIECES  
(TR) PLASTİK CONTA : 6 PARÇA

(FR) JOINT EN PLASTIQUE : 6 PIÉZAS  
(ES) ARANDELAS PLASTICAS : 6 PIECES  
(RU) РЕЗИНОВЫЕ ПРОКЛАДКИ : 6 ШТУКИ

M6 x 30  
2x  
FRONT



'TO SCREW'  
'TO UNSCREW'

5mm



(DE) BENÖTIGTE WERKZEUGE  
(EN) REQUIRED TOOLS  
(TR) GEREKLİ ARAÇLAR  
(FR) OUTILS NECESSAIRE  
(ES) HERRAMIENTAS NECESARIAS  
(RU) РАЗРАБОТАНЫ ДЛЯ АВТОМОБИЛЕЙ

M6 x 65  
2x  
MIDDLE



M6 x 30  
2x  
REAR

