

Germanseil

Car Style

LANDROVER DISCOVERY 4 2009 ≥



BRAND	MODELS	V.TYPES	VERSION	TYPE APPROVAL
LANDROVER	DISCOVERY 4	-	2009 ≥	-

(EN) FITTING INSTRUCTIONS	: PORT BAGAJ
(TR) MONTAJ TALİMATI	: ROOF RAIL
(FR) INSTRUCTIONS DE MONTAGE	: DACHREILING
(ES) INSTRUCCIONES DE MONTAJE	: RIDELLES DE TOIT
(RU) ИНСТРУКЦИЯ ПО УСТАНОВКЕ	: BARRAS DE TECHO
	: РЕЙЛИНГИ

(DE) TEILELISTE
(EN) PART LIST

(FR) LISTA DE ACCESORIOS

(ES) LISTA DI PEZZO
(RU) СПИСОК ДЕТАЛЕЙ



(DE) UNTERLEGSCHIBE : 6 STUCK
(EN) RING WASHER : 6 PIECES



(FR) TUARCE : 6 PIEZAS
(ES) RONDELLE AUTOBLOQUANTE : 6 PIECES
(RU) ШАЙБЫ : 6 ШТУКИ



(DE) GUMMISTOPFEN : 6 STUCK
(EN) PLASTIC PLUG : 6 PIECES



(FR) BOUCHON PLASTIQUE : 6 PIEZAS
(ES) EMPAQUE PARATORNILLO : 6 PIECES
(RU) РЕЗИНОВЫЕ ПРОБКИ : 6 ШТУКИ



(DE) KUNSTSTOFF-DICHTUNG : 6 STUCK
(EN) PLASTIC GASKET : 6 PIECES
(TR) PLASTİK CONTA : 6 PARÇA

(FR) JOINT EN PLASTIQUE : 6 PIEZAS
(ES) ARANDELAS PLASTICAS : 6 PIECES
(RU) РЕЗИНОВЫЕ ПРОКЛАДКИ : 6 ШТУКИ



'TO SCREW'
'TO UNSCREW'

5mm



(DE) BENÖTIGTE WERKZEUGE
(EN) REQUIRED TOOLS
(TR) GEREKLİ ARAÇLAR
(FR) OUTILS NECESSAIRE
(ES) HERRAMIENTAS NECESARIAS
(RU) РАЗРАБОТАНЫ ДЛЯ АВТОМОБИЛЕЙ

